



LOW WATER (9404-03) and STANDARD PUMP (9404-02)



Key	Part #	Description	Key	Part #	Description	Key	Part #	Description
	9404-02	Standard Pump	6	9405-20	Plain Washer	13	9404-22	Suction Plate
	9404-03	Low Water Pump	7	9404-21	Impeller	14	9405-22	Suction Cover
1	9404-27	Hex Bolt w/Washer	8	9404-25	Shaft Sleeve	15	9405-23	Pump Casting
2	9404-32	Strainer	9	9404-26	V - Ring	16	9404-03A	Low Water Pump Base
3	9404-31	Suction Cover	10	9404-34	Pump Casting	17	9404-02A	Stand Sub Pump 2/3 HP Base
4	9404-28	Hex Cap Nut	11	9404-10	Hose Adapter	Accessories (Not Shown)		
5	9404-29	Spring Washer	12	9405-21	Strainer Stand	9404-50	Dewater Pump Hose (50')	