



# LOW WATER (9404-03) and STANDARD PUMP (9404-02)



Key Part #	Description	Key Part #	Description	Key Part #	Description
<b>9404-02</b>	<b>Standard Pump</b>	6	9405-20 Plain Washer	13	9404-22 Suction Plate
<b>9404-03</b>	<b>Low Water Pump</b>	7	9404-21 Impeller	14	9405-22 Suction Cover
1	9404-27 Hex Bolt w/Washer	8	9404-25 Shaft Sleeve	15	9405-23 Pump Casting
2	9404-32 Strainer	9	9404-26 V - Ring	16	9404-03A Low Water Pump Base
3	9404-31 Suction Cover	10	9404-34 Pump Casting	17	9404-02A Stand Sub Pump 2/3 HP Base
4	9404-28 Hex Cap Nut	11	9404-10 Hose Adapter	<b>Accessories (Not Shown)</b>	
5	9404-29 Spring Washer	12	9405-21 Strainer Stand	9404-50	Dewater Pump Hose (50')