SAMPLING PUMPS
(9803, 9803-88, 9803M, 9803-88M, 9804, 9804-88, 9805, 9805-88, 9800, 9800-88)
SAMPLING PUMP ACCESSORIES



Key	Part #	Description
	9803	**T100 Rotary Vane Sampling Pump w/Stand**
	9803-88	**T100 Rotary Vane Sampling Pump w/o Stand**
	9803M	**T100M Rotary Vane Sampling Pump w/Stand**
	9803-88M	**T100M Rotary Vane Sampling Pump w/o Stand**
	9804	**A100 High Volume Sampling Pump w/Stand**
	9804-88	**A100 Sampling Pump w/Stand**
	9805	**Diaphragm Sampling Pump w/Stand**
	9805-88	**Diaphragm Sampling Pump w/o Stand**
	9800	**D2 Moldlite Sampling Pump w/Stand**
	9803	**T100 Rotary Vane Sampling Pump w/Stand**
	9801	**Jarless Sampling Pump w/ Stand**
	9801-88	**Jarless Sampling Pump w/o Stand**
1	9804-07	Tubing * (5 feet)
2	9804-24	Hose Barb
3	9804-04	Variable Flow Regulator

Key	Part #	Description
4	9804-22	Hex Nipple
4A	9805-22	Hex Nipple
5	9804-69	Acorn Nut
6	9804-06	Rubber Feet
7	9803-88MB	Hose Barb
8	9805-15	Handle
9	9805-12	Exhaust Muffle
10	9804-05	Handle
11	9804-41S	Vanes (Set of 4)
12	9805-14	Feet
13	9805-13	Diaphragm
14	9804-71	Muffler Assembly
15	9804-25	Elbow
16	9804-72	Muffler Base
17	9804-01	Filter Element
18	9804-02	Filter Jar
19	9800-54	Feet
20	9804-08	Stand
21	9803-06	Filter Element
22	9804-08B	Stand Knob
23	9800-52	Exhaust Filter
24	9800-53	O-ring and Fastener
25	9803-05	Handle

Key	Part #	Description
26	9803-30S	Vanes (set of 4)
27	9803-88MC	Adaptor
28	9803-88BA	Flow Meter (5-30 LPM)
29	9872-18	Adaptor
30	9804-08C	Stand Top Nut
31	9804-03A	Flow Meter w/o Adaptor (0-20 LPM)
32	9804-03B	Barb
33	9804-07G	Poly Tube 4”
34	9804-79	Adaptor
35	9804-20	M2 Multi-Mold Cassette (Box of 25 Cassettes/50 Samples)
	9804-21	M2 Multi-Mold Cassette (Box of 5 Cassettes/10 Samples)
36	9804-14	Lead Cassette (50 per Box)
37	9804-17	TEM Cassette (50 per Box)
38	9804-16	PCM Cassette (50 per Box)
39	9801-L	Barb
40	9801-06	Filter